PRIORITY SERVICE MAINTENANCE PROGRAM SCHEDULE

Isuzu NPR/NPR-HD/NQR/NRR Diesel

S = scan; I = inspect; A = add; R = replace; L = lubricate; T = torque; Ro = rotate; C = clean

Item \ Miles	4,000	10,000	20,000	30,000	40,000	50,000	60,000	70,000	80,000	90,000	100,000	110,000	120,000	130,000	140,000	150,000	160,000	170,000	180,000	190,000	200,000	210,000	220,000	230,000	240,000	250,000
Download and print DRM Vehicle Health Report	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S
Diagnostic Trouble Codes		S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S
Interior lighting, Switches, Gauges, Warning lights		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Interior controls, Radio, Air conditioning, Heater		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Window regulators, Door locks, Fuses		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Seat belts and Adjusters, Shifter, Foot pedal controls		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Parking brake, Safety kit, Brake fluid		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Windshield washer fluid	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Cab and rear body door hinges		L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Exterior cab and Rear body Lighting		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Cab and rear body bulbs		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Mirrors, Glass, Door operation, Wiper rubbers		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Transmission fluid level		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Tire tread depth/condition	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake pad remaining life/Brake rotor condition	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake shoe remaining life		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Dual battery terminals/Cables		C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L
Air filter element				R			R			R			R			R			R			R			R	
Rear body Door, Domelight, Liftgate	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Engine noise, Exhaust/Oil leakage, EGR cooler	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Engine drive belt tension/condition		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Engine hoses		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Power steering fluid, Brake booster fluid	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A
Engine coolant	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Engine oil and Filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Engine fuel filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
King pins, Universal joints, Center carrier bearing(s)		L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
Rear body mounts		T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T
Diesel particulate filter/Exhaust system		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Tires/Wheels	T	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro	Ro
Engine intake/exhaust valves						A					A					A					A					A
Engine coolant						R					R					R					R					R
Transmission fluid and External filter						R					R					R					R					R
Front wheel bearing grease/seals						R					R					R					R					R
Rear axle fluid						R					R					R					R					R
Leaf spring, Driveshaft and Steering gearbox fasteners						T					T					T					T					T
Windshield wiper blades						R					R					R					R					R
HVAC inlet and outlet filters						C					C					C					C					C
Water pump, Fan and A/C belts											R										R					
Upper and lower radiator hoses											R										R					
Power steering fluid											R										R					
Brake fluid											R										R					
Brake booster fluid (NQR/NRR only)											R										R					
Diesel particulate filter differential pressures											I										I					